

---

# TABLE OF CONTENTS

---

<b>SAFETY NOTICE</b> .....	<b>IX</b>
<b>INTRODUCTION</b> .....	<b>X</b>
GENERAL INFORMATION.....	X
VEHICLE IDENTIFICATION NUMBER (V.I.N.).....	XI
ENGINE IDENTIFICATION NUMBER (E.I.N.) .....	XI
ARRANGEMENT OF THIS MANUAL, ILLUSTRATIONS AND PROCEDURES .....	XI
ENGINE EMISSIONS INFORMATION .....	XIV
SELF-LOCKING FASTENERS PROCEDURE .....	XIV
LOCTITE APPLICATION PROCEDURE.....	XIV
TIGHTENING TORQUES .....	XVIII
<b>01 MAINTENANCE</b>	
<b>01 – MAINTENANCE CHART</b> .....	<b>1</b>
NOISE EMISSION CONTROL SYSTEM REGULATION .....	1
MAINTENANCE CHART .....	2
<b>02 – PRESEASON PREPARATION</b> .....	<b>9</b>
<b>03 – STORAGE PROCEDURES</b> .....	<b>11</b>
VEHICLE CLEANING.....	11
FUEL STABILIZER.....	11
ENGINE LUBRICATION.....	11
RAGS INSTALLATION.....	12
COOLANT DENSITY .....	13
DRIVE AND DRIVEN PULLEYS PROTECTION.....	13
VEHICLE PROTECTION.....	13
<b>04 – SPECIAL PROCEDURES</b> .....	<b>15</b>
TURN OVER .....	15
ATV IMMERSION .....	15
<b>02 TROUBLESHOOTING</b>	
<b>01 – TROUBLESHOOTING CHART</b> .....	<b>17</b>
OUTLANDER 400 SERIES .....	17
COOLING SYSTEM .....	17
MAGNETO SYSTEM .....	18
LUBRICATION.....	20
CYLINDER AND HEAD .....	21
CRANKSHAFT AND BALANCER SHAFT .....	22
GEARBOX.....	23
REWIND STARTER.....	24
CVT.....	25
ENGINE GENERAL.....	29
<b>02 – TROUBLESHOOTING CHART</b> .....	<b>35</b>
OUTLANDER 800 SERIES .....	35
COOLING SYSTEM .....	35
MAGNETO SYSTEM .....	36
LUBRICATION.....	37
CYLINDER AND HEAD .....	39
CRANKSHAFT .....	40
GEARBOX.....	40
DISCONNECT UNIT.....	41
CVT.....	42
ENGINE GENERAL.....	46
<b>03 ENGINE SYSTEM</b>	
<b>01 – AIR INTAKE SILENCER</b> .....	<b>55</b>
OUTLANDER 400 SERIES.....	56