


Rear Wheel Hub Removal/Installation



Requisite Service

- Rear wheel removal/installation (page 12-2)

Procedure		Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Cotter pin	1	
(2)	Castle nut	1	
(3)	Wheel hub	1	