

Install the front crankcase cover and tighten the bolts in 2 or 3 steps in a crisscross pattern.

Install the right engine side cover.

Install the oil cooler pipe (page 4-3).

Pour recommended engine oil (page 3-10).

Make sure there are no oil leaks.

Adjust the clutch (page 3-17).

