
TECHNICAL MANUAL CONTENTS

SECTION	PAGE
1 REFERENCE INFORMATION	3
2 SERVICE TOOLS and SHOP AIDS	13
3 INSTALLATION AND PREDELIVERY	23
4 OPERATION	45
5 ROUTINE SERVICE	55
6 ENGINE COVER SERVICE	71
7 ENGINE MANAGEMENT MODULE (EMM)	77
8 SYSTEM ANALYSIS	95
9 ELECTRICAL AND IGNITION	109
10 FUEL SYSTEM	131
11 OILING SYSTEM	155
12 COOLING SYSTEM	169
13 POWERHEAD	179
14 MIDSECTION	213
15 GEARCASE	233
16 MANUAL STARTER	263
17 TROUBLE CHECK CHART	T-1
18 SERVICE PARTS	P-1
INDEX	I-1
DIAGRAMS	