
TABLE OF CONTENTS

SECTION	SUBSECTION	PAGE
SAFETY NOTICE		III
INTRODUCTION		IV
01	SERVICE TOOLS AND SERVICE PRODUCTS	
	01 – Service Tools	01-01-1
	02 – Service Products	01-02-1
02	LUBRICATION AND MAINTENANCE	
	01 – Lubrication and Maintenance Chart.....	02-01-1
03	TROUBLESHOOTING	
	01 – Table of Contents	03-01-1
	02 – Engine	03-02-1
	03 – Fuel and Oil Systems	03-03-1
	04 – Transmission and Brake Systems	03-04-1
	05 – Electrical System.....	03-05-1
	06 – Suspension and Track	03-06-1
04	ENGINE	
	01 – Table of Contents	04-01-1
	02 – Engine Removal and Installation	04-02-1
	03 – Valve Adjustment	04-03-1
	04 – Disassembly/Assembly	04-04-1
	05 – Compression Test and Engine Dimension Measurement.....	04-05-1
	06 – Transistorized Magneto Ignition	04-06-1
	07 – Rewind Starter	04-07-1
	08 – Carburetor	04-08-1
	09 – Fuel Tank and Throttle Cable.....	04-09-1
05	TRANSMISSION	
	01 – Table of Contents	05-01-1
	02 – Clutch	05-02-1
	03 – Brake	05-03-1
	04 – Drive Chain	05-04-1
06	ELECTRICAL	
	01 – Table of Contents	06-01-1
	02 – Spark Plugs.....	06-02-1
	03 – Testing Procedure	06-03-1
07	REAR SUSPENSION	
	01 – Table of Contents	07-01-1
	02 – Rear Suspension	07-02-1
	03 – Drive Axle	07-03-1
	04 – Track.....	07-04-1
